

Lean back and enjoy the freedom. The **robot lawn mowers** in the **Freelexo** series will take care of cutting the grass. And as a member of the **Power X-Change** family, the device offers all the advantages of an intelligent rechargeable battery system.







YOUR BENEFITS

CORDLESS FREEDOM FOR POWER TOOLS AND GARDEN.

Simply click the battery into place and off you go – be it with a lawn mower, an impact drill or a wet & dry vac. Cordless freedom is a joy.

STATE-OF-THE-ART ENGINEERING. TRIED-AND-TESTED QUALITY.

Our rechargeable batteries are manufactured from only the best components such as high-performance new-generation cells and our intelligent processor- controlled battery electronics. Their quality has been confirmed by **Stiftung Warentest**, for example with its "Test Winner" award for the Power X-Change 2.0 Ah battery.

POWERFUL TOOLS. DURABLE BATTERIES.

Less power? No way! Our cordless tools for real trailblazers are equipped with up to 2700 watts of battery power and are therefore in no way inferior to their corded counterparts!

1 BATTERY. 1000 POSSIBILITIES. EVERYTHING FROM PRUNING SAWS TO MITER SAWS.

The Power X-Change family already contains over **200 tools and items of garden equipment** – and the number is constantly rising. Thanks to the versatile system of rechargeable batteries, the E-Kickscooter from our cooperation partner GOVECS is now also "powered by Power X-Change".



1 BATTERY. 1000 POSSIBILITIES.



Our compatibility promise.
As well as in the robot lawn mowers, the battery pack will also fit in all other tools and units in the . Power X-Change System.









FREELEXO. THE SERIES AT A GLANCE.



TWO WAYS TO YOUR I



COMPLETE PACKAGE





PRODUCT DETAILS				
TECHNICAL DATA	Battery voltage	18 V		
	Cutting width	18 cm		
	Cutting height adjustment	infinitely / 20 - 60 mm / central		
	Suitable for slopes up to	35 %		

DISCOVER THE EINHELL ROBOT LAWN MOWER.

However small or big your garden and lawn, the Einhell range of robot lawn mower models, accessories and options is bound to have the answer to your needs.

NDIVIDUAL FREELEXO



SOLO VARIATION





DIVERSITY FROM EINHELL. MODELS AT A GLANCE.











































FREELEXO			FREELEXO BT			
Art. No.	Lawn area	Battery	Art. No.	Lawn area	Battery	
34.139.61	300 m²	Solo	34.139.48	400 m²	2,0 Ah	
34.139.62	350 m²	2,0 Ah	34.139.49	450 m²	2,0 Ah	
			34.139.44	450 m²	Solo	
			34.139.45	500 m ²	2,5 Ah	
			43.263.63	500 m ²	2,5 Ah	
			34.139.46	600 m²	2,5 Ah	
			34.139.47	1000 m²	4,0 Ah	













































* Larger range thanks to Bluetooth 5.0


FREELEXO LCD BT			FREELEXO LCD BT +			
Art. No.	Lawn area	Battery	Art. No.	Lawn area	Battery	
34.139.53	800 m ²	Solo	34.139.81	750 m ²	3,0 Ah	
34.139.55	900 m ²	3,0 Ah				
43.263.68	1200 m ²	5,2 Ah				
_						

FIND THE RIGHT BATTERY FOR YOUR GARDEN.

Recommended battery packs

			pacito			
1200 m²						
1100 m²						
1000 m²						
900 m²						
800 m ²						
700 m ²						
600 m ²						
500 m ²						
400 m²						
300 m ²						
200 m²						
100 m²						
	2,0 Ah	2,5 Ah	3,0 Ah	4,0 Ah	5,2 Ah	6,0 Ah








EINHELL ROBOT LAWN MOWER SERIES.

FREELEXO





SUSTAINABLE Thanks to mulching function. The chopped-up cut grass drops down to the sward, where it acts as a natural fertilizer down into the roots and protects

AUTONOMOUS

The Freelexo **automatically** returns to and gets **charged up** by the charging unit if required.



the lawn.



ADAPTABLE

Also suitable for bumpy gardens – with the ability to master slopes of up to 35%.

MORE THAN JUST A ROBOT LAWN MOWER.

THE BEST FEATURES IN BRIEF.

INDIVIDUAL

The Freelexo is controlled via **app** by **Bluetooth** – the operating time can be precisely programmed for each specific day.





VARIABLE

With the mowing program for **secondary areas** you can also provide optimum care for areas **separated from the main garden**.



SAFE

Impact, tilt and lift sensors automatically detect obstructions.



Tight spots up to 80 cm between perimeter cables are also no problem for the robot lawn mowers in the Freelexo series.





SPOT ON

Thanks to the **spot mowing** function you can
pin-point the cutting of **hard-to-reach areas** such
as under garden furniture.

VERSATILE

Using the multi-zone mowing mode, the robot lawn mowers are even suitable for irregularly shaped gardens.





ENERGY-EFFICIENT

In **Eco Mode** the loop signal switches off automatically as soon as the robot lawn mower is in the charging station. This **saves you** money and protects the environment.





INTUITIVE

Control inputs via the intuitive **keypad** or **LCD display**. PIN code for anti-theft protection.

BEAUTIFUL LAWN AT THE PUSH OF A BUTTON.

DOWNLOAD THE FREE APP!



Thanks to Bluetooth functionality, Freelexo robot lawn mowers offer individual adjustment options that you can access and set up comfortably from a smartphone app.

Use these options to start the robot lawn mower, to set fixed mowing times, to look at statistics and define many more practical settings – just how you want them.

Fancy a look at the app? Download the iOS or Android app and activate demo mode.













ROBOT LAWN MOWERS ACCESSORIES – JUST IN CASE.



Want to extend the lawn area? Need a replacement blade? Want a clean & care set to reward your robot lawn mower? Our range of accessories has everything you need.

ROBOT LAWN MOWERS ACCESSORIES					
gnation	Art. No.	Items supplied			
neter wire	34.140.21	50 m			
e blades	34.140.20	12 pcs			
ning hooks	34.140.23	100 pcs			
ection clamps	34.140.22	4 pcs			
Repair set		5 m Perimeter wire, 15 pcs Fastening hooks, 8 pcs Connection clamps			
ning set	34.140.25	Brush, sanding pads, gloves, microfiber cloth, screwdriver, spatula			
	ignation neter wire e blades ening hooks nection clamps	ignation Art. No. neter wire 34.140.21 e blades 34.140.20 nining hooks 34.140.23 nection clamps 34.140.22 air set 34.140.26			

INSTALLATION. DIY - DO IT YOURSELF.

Installation couldn't be easier - just follow our videos



www.einhell-service.com/maehroboter-service

Short on time? No problem, thanks to our

COMMISSIONING SERVICE



We will be happy to help you lay out the perimeter wire and set up the device ready for use. We can send our experts out to your home.

Please contact our installation service team under these numbers or email addresses:

DE: +49 9951 959 2036 Service-DE@einhell.com AT: +43 1 205 335 16 Service-AT@einhell.com



QUESTIONS?



Commissioning service: DE: +49 9951 959 2036

AT: +43 1 205 335 16

General questions: DE: +49 9951 959 2037

AT: +43 1 205 335 17

Help with self-installation: DE: +49 9951 959 2035

AT: +43 1 205 335 15

E-Mail: DE: Service-DE@einhell.com

AT: Service-AT@einhell.com

For other services and further information please visit our website. www.einhell-service.com/Installation



FAQ – FREQUENTLY ASKED QUESTIONS.

WHAT PRINCIPLE DOES THE ROBOT LAWN MOWER FOLLOW?

Robot lawn mowers operate on a random principle. If the mower reaches an obstruction or the perimeter wire, it rotates in a random direction and continues its work,. In addition, the the mower switches into a spiral mode several times during every working window in order to improve the efficiency of the random principle.

IS THE ROBOT ALSO SUITABLE FOR MORE COMPLEX GARDENS?

Thanks to the Multi-area Mowing Function, even complex gardens can be mowed reliably. Various starting positions can be defined with this function. This allows the mower to move through narrow corridors and reach even areas at awkward angles. The robot lawn mower covers the distance to the starting point on the perimeter wire and then starts with the actual mowing process once it reaches the target zone.

WHAT IS THE MAXIMUM SLOPE THAT THE MOWER CAN DEAL WITH?

The robot lawn mower can handle slopes of up to 35%.

WHAT FUNCTIONS DOES THE CORRESPONDING APP OFFER?

In addition to normal operation, you can also establish a connection to the device via Bluetooth. As well as controlling the robot lawn mower, checking the settings and programming the mower, you can also view its current status and statistics.

HOW CAN THE PERIMETER WIRE BE ROUTED?

The perimeter wire can be routed either above ground or at a depth of up to 5 cm in the soil. We recommend installation above ground so that you can still make corrections easily during the first few days of use. The wire will be overgrown within a few weeks and almost impossible to see.

IS THE ROBOT LAWN MOWER RAIN PROOF?

Rain is not a problem for Einhell robot lawn mowers. However, thanks to the built-in rain sensor, if it does rain the mower will return to the charging station to protect the lawn.



FREELEXO

TURN MOWING TIME INTO LEISURE TIME.



Einhell Germany AG Wiesenweg 22

Wiesenweg 22 94405 Landau/Isar Germany

info@einhell.de www.einhell.de einhell.com

© 2021 Einhell Germany AG | Subject to change without notice. E&OE. | Art. No. 110668 / 03 - As of 01.2021